

iSMA Configurator

User Manual



Table of content

1	Introduction.....	3
1.1	Revision history	3
1.2	Software requirements.....	3
1.3	General purpose of iSMA Configurator software	3
1.4	Naming and its definition.....	7
1.5	Internet access and firmware availability.....	8
2	How to connect iSMA-Configurator to devices	10
2.1	Direct Ethernet connection	10
2.2	Connection to RS485 bus	10
2.3	Connection to USB	14
3	Main functions	16
3.1	Upgrade.....	17
3.2	Resetting the Module	18
3.3	Reload Settings.....	19
3.4	Default Settings	20
4	Device configurations	21
5	Projects.....	22
6	Discovering the Devices	23
6.1	Discovering Devices for Modbus via RS485	24
6.2	Discovering Devices for Modbus via TCP/IP	28
6.3	Discovering Devices via RS485 connected to IP Gateway.....	30
6.4	Discovering Devices for BACnet via RS485	33
6.5	Discovering Devices for BACnet IP	35
7	Adding and removing the devices manually	40

1 Introduction

1.1 Revision history

Rev	Date	Description
1.0	21.12.2017	<ul style="list-style-type: none"> • First edition

Table 1 - Revision History

1.2 Software requirements

Windows compatibility – iSMA Configurator is an application intended for Windows only, and it can be run on Windows 7, 8 and 10.

There is no need to install any additional software or drivers in order to run iSMA Configurator.

1.3 General purpose of iSMA Configurator software

The iSMA Configurator software is designed to perform configuration, firmware update and diagnosis of the non-programmable iSMA devices. The iSMA Configurator can communicate with configurable modules via RS485, TCP/IP or USB COM Port. The software is free and can be obtained from your distribution partner or downloaded from the support server at www.support.gc5.pl.

iSMA Configurator allows for the following actions:

- Downloading the latest firmware versions to your PC from Global Control 5 Sp. z o.o. server;
- Uploading new firmware on devices;
- Creating/saving/loading the list of discovered devices (Project);
- Resetting devices;
- Reloading device settings;

- Restoring device configurations to default settings;
- Configuring devices;
- Changing or viewing communication parameters of the devices;
- Discovering gateway devices.

iSMA Configurator allows for five types of communication:

- Modbus RTU - with the RS485 port;
- Modbus TCP/IP - with IP port;
- BACnet MS/TP - with the RS485 port;
- BACnet IP - with IP port;
- USB - with the direct USB cable connection.

Information about type of communication, firmware upgrade and configuration possibilities is described in the tables below.

Device	Firmware update				
	Modbus RTU	Modbus TCP/IP	BACnet MS/TP	BACnet IP	USB
MIX series	✓	✓ (only via Gateway device)	✓ (from FW 6.0 and HW 2.0)	X	✓
MIX-IP series	✓	✓	✓ (from FW 6.0)	✓ (from FW 6.0)	✓
MINI Series	✓	✓ (only via Gateway device)	✓ (from FW 6.0)	X	✓
MINI-IP Series	✓	✓	✓ (from FW 6.0)	✓ (from FW 6.0)	✓
FCU	X	X	X	X	X
LP	✓	✓ (only via Gateway device)	✓	X	✓
2D1B	✓	✓	X	X	✓

		(only via Gateway device)			
2D	✓	✓ (only via Gateway device)	✗	✗	✓
AAC20	✗	✗	✗	✗	✗
AAC20-LCD	✗	✗	✗	✗	✗
W0202	✓	✓ (only via Gateway device)	✗	✗	✓
MG-IP	✓	✓	✗	✗	✓

Table 2 - iSMA Configurator Firmware update possibilities

Device	Configuration				
	Modbus RTU	Modbus TCP/IP	BACnet MS/TP	BACnet IP	USB
MIX series	✓	✓ (only via Gateway device)	✓ (completely from FW 6.0)	✓ (completely from FW 6.0)	✓
MIX-IP series	✗	✓	✗	✓ (from FW 6.0)	✓
MINI Series	✓	✓ (only via Gateway device)	✓ (from FW 6.0)	✓ (from FW 6.0)	✓
MINI-IP Series	✗	✓	✗	✓ (from FW 6.0)	✓
FCU	✓	✓ (only via Gateway device)	✓	✗	✓

LP	✓	✓ (only via Gateway device)	✓ (read only)	✗	✓
2D1B	✓	✓ (only via Gateway device)	✗	✗	✓
2D	✓	✓ (only via Gateway device)	✗	✗	✓
AAC20	✗	✓	✗	✓	✓
AAC20-LCD	✗	✓	✗	✓	✓
W0202	✓	✓ (only via Gateway device)	✗	✗	✓
MG-IP	✗	✓	✗	✗	✓

Table 3 - iSMA Configurator configuration possibilities

1.4 Naming and its definition

iSMA Configurator communicates with one or more devices and transfers data in both directions. It is crucial for distinguishing the direction of data flow as described below:

- **Read module** – transfers the data from the module to PC, for example when you want to see how the module was configured.
- **Write module** – transfers the data from the PC to the module, for example when you have made changes in module configuration and you want to send them to the module.




Figure 1 – communication transfer directions

1.5 Internet access and firmware availability

When the iSMA Configurator is operated for the first time, it is recommended to have Internet access on a local PC in order to be able to download the latest firmware versions. The application connects with the Global Control 5 Sp. z o.o. server and informs the user that there are newer firmware versions for downloading. Information about new firmware versions is presented in a pop-up window as in the figure below.




Figure 2 – First run

If the new firmware is available, the user can download it by pressing 'Download Latest Firmware' button. When iSMA Configurator finishes the downloading, a message pop-up window shows which firmware was downloaded. In case if you have all latest firmware versions, you will have the message as in the figure below.



Figure 3 – Firmware versions check

2 How to connect iSMA-Configurator to devices

There are three general ways to connect iSMA-Configurator to the configurable devices:

1. Direct Ethernet connection
2. RS 485 bus
3. USB cable

2.1 Direct Ethernet connection

In case of direct Ethernet connection the iSMA-Configurator used devices IP address to connect to it. To be able to add or discover the device you must first be within the device IP range. In order to make new device configurations, user must change its computer IP so that is within the same IP range. As the device's default IP is 192.168.1.123 when shipped, user can use, for example 192.168.1.11.

2.2 Connection to RS485 bus

Connecting the iSMA Configurator to the RS485 bus is recommended on a site where all the devices are linked together. The RS485 network needs to be connected to the PC with the iSMA Configurator software running. If the PC is not equipped with the RS485 communication port, a converter is required. Global Control 5 Sp. z o.o. company recommends using a iSMA-B-CVT-RS485 converter, sold separately.




Figure 4 - RS485 converter

Note: Before connecting the PC to the iSMA Configurator running on the RS485 network, it is recommended to disconnect the master controller. The next step is to connect the PC via the RS485 converter (if required) and to run the iSMA Configurator. After this, the new project needs to be opened or created. When finished, setup all the required transmission settings, and the transmission will start. The transmission settings for the Modbus and BACnet protocols are described below.

Note: Once the operation with the iSMA Configurator is finished, please remember to disconnect the PC from the RS485 network and reconnect the master unit.

In order to configure the RS485 connection, click on the “Configure connection” button.




Figure 5 – Configure connection

Depending on the protocol chosen, the following transmission settings are required:

for BACnet communication protocol:

- 'COM Port' – COM port used for the BACnet MSTP communication to which the RS485 bus is attached;
- 'Baud rate' – baud rate for communication;
- 'Timeout' - time the driver will wait for an expected response from the device before retrying or going on to the next request.
- 'Software Device ID' – the BACnet ID of the local PC. It must be different from the ones for the other devices connected to BACnet bus.

for Modbus communication protocol:

- 'COM Port' – the COM port used for the Modbus RTU communication to which the RS485 bus is attached;
- 'Baud rate' – baud rate for communication;

- 'Parity Bits' – defining parity bits; available options: None, Even, Odd.

The image shows a 'Configure Connection' dialog box with three main sections, each highlighted with a red box:

- Modbus RS485 Configuration:**
 - Port: COM3
 - Baudrate: 115200
 - Parity: None
 - Data bits: 8
 - Stop bits: 1
- BACnet MSTP Configuration:**
 - Port: COM10
 - Baudrate: 115200
 - Timeout [s]: 30
 - Software BacnetID: 0
- BACnet IP Configuration:**
 - Interface: Intel(R) Dual Band Wireless-AC 8265
 - Ip Address: 172.16.1.135
 - Timeout [s]: 30
 - Port: BAC0

At the bottom of the dialog are 'OK' and 'Cancel' buttons.

Figure 6 – Modbus / BACnet RS485 Configurations

2.3 Connection to USB

Each configurable iSMA device is equipped with one mini USB type B available on its board which allows for connecting directly to a PC with the iSMA Configurator running. This USB connection automatically configures the communication COM port on the PC and enables adequate functions on the iSMA Configurator. The USB connection also provides power supply of the devices, so they can be configured without any additional power source.

Note: With USB cable connected to the mini USB slot on the device it is possible to operate only on one device which was automatically recognised as attached to the controller and appears under “USB” branch.



Figure 7 - Direct connection to iSMA-B-LP panel

After direct connecting of the controller or the panel to the PC, the system automatically recognises the attached device and shows it in the main table assuming that a project is already opened. No particular communication settings are required for setting transmission parameters or starting the transmission.

Note: The direct connection with USB cable can only be setup to one device at the time. To stop the direct connection simply disconnect the cable.




Figure 8 – Device connected via USB cable

3 Main functions

After selecting a marked device, the following functions are available:

- Upgrade;
- Reset Module;
- Reload Settings;
- Default Settings.



Figure 9 - Direct connection to the device with USB cable

3.1 Upgrade

The Upgrade function allows the user for upgrading the firmware of the device if necessary. Before starting the Upgrade process it is recommended to check if new versions of firmware are available by clicking “Download newest firmwares”. The Upgrade function can be executed only for one device at a time.

Note: Devices with hardware version older than 2.0 and/or firmware versions older than 6.0 cannot be Upgraded via BACnet.




Figure 10 - Upgrade option

3.2 Resetting the Module

Resetting the module should be the first action that the user performs in case of problems with the controller or application functionality in general. The restarting procedure forces the application to start the execution of the program from the beginning and initiates reading raw values for inputs.

Note: It is recommended to restart the application before contacting the technical support.



Figure 11 – Resetting the device

3.3 Reload Settings

In order to be able to made all required changes in communication, without loosing connection with the module, “Reload Settings” function was implemented. The “Reload Settings” function initialize all the previously changed communication parameters.




Figure 12 – Reload Settings

3.4 Default Settings

The 'Default Settings' button sets all parameters of the controller to their initial (default) values. All the NV parameters in the application are set to their default values. All communication settings that are not configured with DIP switches are set to their default values as well.

Warning: "Default Settings" procedure will erase all settings previously made by user!

Note: The procedure of resetting to default values is recommended in the following cases:

- controlled physical object has been replaced;
- the role of the controller in the network has been changed with regard to master-slave configuration;
- the application does not work properly and restarting of the application with its default parameters can help.

To perform the action of setting to default values, select the device and press the 'Default Settings' button. The iSMA Configurator sends a special request to the device.



Figure 13 - Setting to default settings

4 Device configurations

There are two ways to configure devices in iSMA Configurator: in “online” and “offline” mode. When a device is discovered, double click on it and choose one of the abovementioned methods.

In case of “offline” mode it is crucial to click “Read Module” in order to learn what are the configurations of the chosen module in that moment. Successful Read operation is confirmed by pop-up window with “Read successful” message. After that, the user can make all the changes and send them to the controller by clicking the “Write Module” button. Successful Write operation is confirmed with pop-up window with “Write successful” message.




Figure 14 – Configuring device in “offline” mode

In order to configure the module in “online” mode, click on the “Switch to Online” button. In that case every change in configuration is sent immediately to the controller. “Read module” and “Write module” are not available in that mode.




Figure 15 – Configuring device in “online” mode

5 Projects

For user convenience, iSMA Configurator is equipped with Configuration Database which can be used for creating lists of the devices discovered in every project. For example, if the user has three projects (buildings) with their unique lists of the devices, there is no need to perform the discovery process every time when he connects to the network. Projects can be saved for each field object and stored on local PC for future use.

The process of saving the configuration is very simple. After finishing the discovery, the user should save the configuration using “Save Configuration” button. The configuration file will be saved to the location chosen by the user and can be used next time by clicking the “Load Configuration” button and choosing the appropriate configuration file. “New Configuration” button is used to clear the list of discovered devices and create a new empty project. Every time when iSMA Configurator is opened for the first time, a new project is created.




Figure 16 – Configuration buttons

6 Discovering the Devices

If the connection to Modbus or BACnet network is properly set up, it is possible to discover all the devices physically connected on the bus. The process of discovery involves recognizing the type of the device along with its address in the network. Each device discovered is automatically added to the table of the current project, so that the user does not need to know the type, address, and number of devices connected on the bus. The process of discovery is fast, and it is recommended to run it at the beginning to have an overview of the whole network.

It is possible to start the discovering process by pressing the 'Discover Devices' button or by right-clicking on the protocol in the navigation tree. The discovering process requires some individual settings depending on the protocol type.

Press the 'Discover' button to run the identification process. It is possible to abort this process without adding any devices to the table in the project, by pressing the 'Cancel' button. If the

number of already identified devices is satisfactory, the user can stop the further process and all he needs to do is to add the devices found to the table by pressing the 'Finish' button.




Figure 17 - Discovering process in progress

There are five types of possible discovery methods:

- Devices directly connected to RS485 port via Modbus RTU;
- Devices directly connected to RS485 port via BACnet MS/TP;
- Devices connected to IP port via Modbus TCP/IP;
- Devices connected to IP port via BACnet IP;
- Devices with RS485 port connected to an IP Gateway device via Modbus TCP/IP.

The above situations are described in the chapters below.

6.1 Discovering Devices for Modbus via RS485

In its standard version, Modbus is not equipped with discovery function, but in case of iSMA-Devices we are able to perform the discovery using our iSMA Configurator software.

In case your PC is not equipped with RS485 port, it is required to have RS485/USB converter in order to start discovery process. It is important to check the communication parameters before starting the discovery. An example of device connection is shown in the figure below.

Note: Before connecting the PC to the iSMA Configurator running on the RS485 network, it is recommended to disconnect the master controller.




Figure 18 – Devices connected directly via Modbus RS485

The image shows a 'Configure Connection' dialog box with three main configuration sections. The 'Modbus RS485 Configuration' section is highlighted with a red border and contains the following settings: Port (COM3), Baudrate (115200), Parity (None), Data bits (8), and Stop bits (1). The 'BACnet MSTP Configuration' section contains: Port (COM10), Baudrate (115200), Timeout [s] (30), and Software BacnetID (0). The 'BACnet IP Configuration' section contains: Interface (Intel(R) Dual Band Wireless-AC 8265), Ip Address (172.16.1.135), Timeout [s] (60), and Port (BAC0). At the bottom of the dialog are 'OK' and 'Cancel' buttons.

Section	Parameter	Value
Modbus RS485 Configuration	Port	COM3
	Baudrate	115200
	Parity	None
	Data bits	8
	Stop bits	1
BACnet MSTP Configuration	Port	COM10
	Baudrate	115200
	Timeout [s]	30
	Software BacnetID	0
BACnet IP Configuration	Interface	Intel(R) Dual Band Wireless-AC 8265
	Ip Address	172.16.1.135
	Timeout [s]	60
	Port	BAC0
	Buttons	OK / Cancel

Figure 19 – Modbus RS485 Configuration parameters

Before beginning the discovery process, it is necessary to setup the range of the addresses. The iSMA Configurator starts searching for the first device with the given address in the 'Start Address' field until reaching the last device with the address specified in the 'Stop Address' field. The time spent on discovering varies depends on the range of the devices and on the

network's baud rate. To reduce the detecting time, it is recommended to adjust the range accordingly.




Figure 20 – Address range for device detection

After the discovery process is finished, devices appear in the navigation tree, under RS485 branch. Device types and their Modbus addresses are identified automatically.




Figure 21 - Devices discovered via Modbus RS485

6.2 Discovering Devices for Modbus via TCP/IP

It is possible to discover the devices via Modbus TCP/IP if your network is built on IP devices. In order to start discovery, make sure that your PC is connected to the same network as the devices and it has IP address in the same network segment.

An example of device connection is shown in the figure below.




Figure 22 – Devices connected via Modbus TCP/IP

In case of Modbus TCP, the devices discovered recently appear in the list only with IP address and information that they are not identified. In order to make any changes to the devices, it is crucial to identify them. To do so, right click on the device in the tree and choose “Identify and Discover Gateway Devices” option.



Figure 23 - Devices discovered via Modbus TCP

6.3 Discovering Devices via RS485 connected to IP Gateway

It is a common practice to have one IP Gateway device in the network and a couple of other connected via RS485. In that case, your PC with iSMA Configurator should be connected to the same network as Gateway device and have an IP address in the same network segment. Make sure that RS485 configuration parameters in the Gateway device are set accordingly so that it is possible to discover the Modbus devices connected to the bus.




Figure 25 - Gateway devices discovered via Modbus TCP

6.4 Discovering Devices for BACnet via RS485

Except for standard configurations (COM Port; Baud Rate) for BACnet protocol, it is required to define the timeout and Software BACnet ID. The user is asked to set the timeout at the 'Timeout in second' field to guarantee enough time to find all the devices on the BACnet bus. Choosing the correct value depends on the network's baud rate (inversely proportionally) and the number of devices (proportionally) connected to the BACnet bus.

Software BACnet ID parameter allows for the user to change software ID in order to make sure it is not duplicated on the network.



The image shows a 'Configure Connection' dialog box with three main sections: 'Modbus RS485 Configuration', 'BACnet MSTP Configuration', and 'BACnet IP Configuration'. The 'BACnet MSTP Configuration' section is highlighted with a red border. The 'Modbus RS485 Configuration' section includes fields for Port (COM3), Baudrate (115200), Parity (None), Data bits (8), and Stop bits (1). The 'BACnet MSTP Configuration' section includes fields for Port (COM10), Baudrate (115200), Timeout [s] (30), and Software BacnetID (0). The 'BACnet IP Configuration' section includes fields for Interface (Intel(R) Dual Band Wireless-AC 8265), Ip Address (172.16.1.135), Timeout [s] (60), and Port (BAC0). At the bottom, there are 'OK' and 'Cancel' buttons.

Section	Parameter	Value
Modbus RS485 Configuration	Port	COM3
	Baudrate	115200
	Parity	None
	Data bits	8
	Stop bits	1
BACnet MSTP Configuration	Port	COM10
	Baudrate	115200
	Timeout [s]	30
	Software BacnetID	0
BACnet IP Configuration	Interface	Intel(R) Dual Band Wireless-AC 8265
	Ip Address	172.16.1.135
	Timeout [s]	60
	Port	BAC0
	Buttons	OK, Cancel

Figure 26 – BACnet MS/TP Configuration parameters




Figure 27 - Discovering devices for BACnet




Figure 28 - Discovering process for BACnet in progress

In case your PC is not equipped with RS485 port, it is required to have RS485/USB converter in order to start discovery process. It is important to check the communication parameters before starting the discovery. An example of device connection is shown in the figure below.

Note: Before connecting the PC to the iSMA Configurator running on the RS485 network, it is recommended to disconnect the master controller.




Figure 29 – Devices connected directly via BACnet RS485

Note: If all the devices are not found after the first scanning process is complete, increase the timeout value. If some missing controllers are still found, add the missing devices manually by pressing the 'Add Device' button. The devices discovered or added manually become visible under the BACnet IP branch with their ID and IP address, as in the figure below.

6.5 Discovering Devices for BACnet IP

It is possible to discover devices via BACnet IP if your network is built on IP devices. In order to start the discovery, make sure that your PC is connected to the same network as the devices and has IP address in the same network segment.

An example of device connection is shown in the figure below.




Figure 30 – Devices connected via BACnet IP




Figure 31 – BACnet IP Connection Configurations

The image shows a 'Configure Connection' dialog box with three main sections:

- Modbus RS485 Configuration:**
 - Port: COM3
 - Baudrate: 115200
 - Parity: None
 - Data bits: 8
 - Stop bits: 1
- BACnet MSTP Configuration:**
 - Port: COM10
 - Baudrate: 115200
 - Timeout [s]: 30
 - Software BacnetID: 0
- BACnet IP Configuration (highlighted with a red box):**
 - Interface: Intel(R) Ethernet Connection (4) I219
 - Ip Address: 192.168.10.177
 - Timeout [s]: 60
 - Port: BAC0

At the bottom of the dialog are 'OK' and 'Cancel' buttons.

Figure 32 – BACnet IP Connection Configuration details

Before starting the discovery process, it is necessary to start BACnet IP Transmission. If the user forgets to do so, iSMA Configurator will remind to do it in a pop-up window.




Figure 33 – Starting BACnet IP Transmission

Note: If all the devices are not found after the first scanning process is complete, increase the timeout value. If some missing controllers are still found, add the missing devices manually by pressing the 'Add Device' button. The devices discovered or added manually become visible under the BACnet IP branch with their ID and IP address, as in the figure below.




Figure 34 – Devices discovered via BACnet IP

7 Adding and removing the devices manually

Adding a device to the table or removing it allows for a manual manipulation. Both functions (adding and removing) can be used either online or offline, even without starting the transmission. This approach allows the user to edit the list of devices on any project before arriving on the site.

The function of discovering devices along with adding and removing option helps the user to build a virtual list of all physical devices installed on the Modbus or BACnet network.

Note: It is recommended to do discovery process first, because starting discovery will erase the list of previously added devices.





Figure 35 - Add Device

The process of adding a new device varies depending on the type of connection chosen for the project. Both protocol types ask for unique device identification on the bus. In case of Modbus the Modbus address (MAC address field) is required, but in BACnet the BACnet ID is

needed. To simplify the process, the system automatically calculates and proposes a BACnet ID basing on the MAC Address typed, assuming that BACnet net is built with default 82600 sub-net (provided by BACnet organisation to all Global Control 5 Sp. z o.o. devices).



The screenshot shows a dialog box titled "Add Module" with the following fields and options:

- Modbus Protocol:** A dropdown menu currently showing "ModbusRS485".
- IP Address:** A text input field containing "192.168.10.230".
- TCP Port:** A text input field containing "502".
- Modbus Address:** A text input field containing "1".
- Module Type:** A list box with a tree view structure containing the following items:
 - IO Modules (highlighted in blue)
 - FCU Modules
 - DDC Modules
 - Wireless Modules
 - Meter Gateway Modules

At the bottom of the dialog, there are two buttons: "OK" and "Cancel".

Figure 36 - Adding a device on Modbus manually

Add BACnet Module

Protocol: BACnet MSTP

Device BACnet ID: 826001

Device MAC Address: 2

Device IP: 192.168.1.123

Device Port: BAC0

Module Type

- IO Modules
- FCU Modules
- DDC Modules

OK Cancel

Figure 37 - Adding a device on BACnet manually

To remove the devices from the project, right click on the device and choose the “Delete” option from the list.




Figure 38 – Removing the devices manually

It is possible to add the device to the list automatically (to extend the list of devices) as soon as the physical unit is connected to the iSMA Configurator directly with the cable. This feature is convenient when there is a controller that is not yet attached to the bus, but the user can easily connect a USB cable to it. The next chapter describes this process in more detail.